

Hämeenkatu 9  
05800 HYVINKÄÄ  
Tel. 020 789 5900  
www.fescon.fi

## SANITARY SILICONE



### Product description

Fescon Sanitary Silicone is a one-component silicone mass for expansion joints and sealing. The mass is suitable for use in wet areas, and the silicone tints match those of the Fescon Tile Seaming Plaster.

- Easy to use
- Contains an anti-mould additive
- Cannot be overcoated
- Not suitable for aquariums or swimming pools
- Several colours



### Instructions

### Work instructions

- Unscrew the plug of the extrusion tip and cut open the cone at the end. Screw the extrusion tip into place and cut it down to the desired size.
- The grouting base must be dry and free of dust and grease.
- Squeeze the silicone mass into the seam and immediately smooth it out with a joint knife or a finger moistened with clean water.
- When redoing the seams, the old silicone must be removed so must spots of mould and other substances reducing adhesion.

### Service instructions

- In wet areas, the silicone seams must be checked regularly and replaced if necessary, and at least every five years.
- The product is not suitable for overpainting or for use in aquariums or swimming pools.

### Waste handling

Storage and handling of waste

See the separate storage and disposal instructions <https://www.fescon.fi/en/material-bank>

Hämeenkatu 9  
05800 HYVINKÄÄ  
Tel. 020 789 5900  
www.fescon.fi

## Technical information

<b>Material usage</b>	Approx 12 m of 5*5 seam / cartridg
<b>Binder</b>	Silicone polymer
<b>Package size</b>	300 ml cartridge
<b>Storage</b>	In a warm location below +25°C, see package for the best before date
<b>Density</b>	Approx. 1.0 - 1.4 kg / dm
<b>Usage temperature</b>	Recommended +18°C...+22°C (however between +5°C...+35°C)
<b>Shrinkage</b>	< 5%
<b>Heat resistance</b>	-40°C..+150°C

Limitation of liability, product use notes and restrictions: Please familiarize yourself with Fescon Oy's general terms of delivery and the design and work instructions related to the product.