

Hämeenkatu 9
05800 HYVINKÄÄ
Tel. 020 789 5900
www.fescon.fi

SANITARY SILICONE



Product description

Fescon Sanitary Silicone is a one-component silicone mass for expansion joints and sealing. The mass is suitable for use in wet areas, and the silicone tints match those of the Fescon Tile Seaming Plaster.

- Easy to use
- Contains an anti-mould additive
- Cannot be overcoated
- Not suitable for aquariums or swimming pools
- Several colours



Instructions

Work instructions

- Unscrew the plug of the extrusion tip and cut open the cone at the end. Screw the extrusion tip into place and cut it down to the desired size.
- The grouting base must be dry and free of dust and grease.
- Squeeze the silicone mass into the seam and immediately smooth it out with a joint knife or a finger moistened with clean water.
- When redoing the seams, the old silicone must be removed so must spots of mould and other substances reducing adhesion.

Service instructions

- In wet areas, the silicone seams must be checked regularly and replaced if necessary, and at least every five years.
- The product is not suitable for overpainting or for use in aquariums or swimming pools.

Waste handling

Storage and handling of waste

See the separate storage and disposal instructions <https://www.fescon.fi/en/material-bank>

Hämeenkatu 9
05800 HYVINKÄÄ
Tel. 020 789 5900
www.fescon.fi

Technical information

Material usage	Approx 12 m of 5*5 seam / cartridg
Binder	Silicone polymer
Package size	300 ml cartridge
Storage	In a warm location below +25°C, see package for the best before date
Density	Approx. 1.0 - 1.4 kg / dm
Usage temperature	Recommended +18°C...+22°C (however between +5°C...+35°C)
Shrinkage	< 5%
Heat resistance	-40°C..+150°C

Limitation of liability, product use notes and restrictions: Please familiarize yourself with Fescon Oy's general terms of delivery and the design and work instructions related to the product.