

Updated 27.1.2023 Printed 29.3.2024

Hämeenkatu 9 05800 HYVINKÄÄ Tel. 020 789 5900 www.fescon.fi


SANITARY SILICONE



Product description

Fescon Sanitary Silicone is a one-component silicone mass for expansion joints and sealing. The mass is suitable for use in wet areas, and the silicone tints match those of the Fescon Tile Seaming Plaster.

- Easy to use
- Contains an anti-mould additive
- Cannot be overcoated
- Not suitable for aquariums or swimming pools
- Several colours



Instructions

Work instructions

- Unscrew the plug of the extrusion tip and cut open the cone at the end. Screw the extrusion tip into place and cut it down to the desired size.
- The grouting base must be dry and free of dust and grease.
- Squeeze the silicone mass into the seam and immediately smooth it out with a joint knife or a finger moistened with clean water.
- When redoing the seams, the old silicone must be removed so must spots of mould and other substances reducing adhesion.

Service instructions

- In wet areas, the silicone seams must be checked regularly and replaced if necessary, and at least every five years.
- The product is not suitable for overpainting or for use in aquariums or swimming pools.

Waste handling

Storage and handling of waste

See the separate storage and disposal instructions https://www.fescon.fi/en/material-bank





Updated 27.1.2023 Printed 29.3.2024

Hämeenkatu 9 05800 HYVINKÄÄ Tel. 020 789 5900 www.fescon.fi

Technical information

approx 12 m of 5*5 seam / cartridg
silicone polymer
300 ml cartridge
in a warm location below +25°C, see package for the best before date
approx. 1.0 - 1.4 kg / dm
recommended +18°C+22°C (however between +5°C+35°C)
< 5%
-40°C+150°C